



Rear Tag Frame SS Carbon Fiber Colors

2010-2013



AMERICAN CAR CRAFT INSTRUCTIONS

Camaro Rear Tag Frame "SS" Lettering Carbon Fiber Colors

Part #102097



PARTS INCLUDED:

- 1-Chrome/Stainless/Carbon Fiber Tag Frame
- 2-M6-1.0x20mm Zinc Plated Course Head
- 2-124NC 10mmChrome Screw Covers

1. Remove screws from stock license frame.
2. Install new Tag Frame and install new hardware.
3. Snap Chrome Screw Covers over screw head.

Thank you and enjoy your purchase!

If any questions occur during installation please contact
AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com