



AMERICAN CAR CRAFT INSTRUCTIONS

CAMARO POLISHED **TRIBAL FLAME** FUEL RAIL COVERS

PART#103010



PARTS INCLUDED:

- 2-Stainless Fuel Rail Covers
- 1-Adhesive Promoter Pack

These new fuel rail covers have been designed to attach directly to the factory engine shroud offering a nice upgrade and restyling to the engine bay.

Your new covers come with a protective liner; do not remove liner until installation is complete.

1. Thoroughly scrub clean the area to be mounted with alcohol to remove any and all road grime and wax. Then swipe the entire area with the adhesive promoter provided.
2. Before you permanently attach the new covers place each of them in position to check the overall fitment and make any subtle adjustments by hand until they sit just right.

3. Once you are satisfied with the fit simply peel the red release liner from the back of the new cover and then firmly press them in place. Remove the protective liner.

**If you have any questions during installation please call American Car Craft
at 727-861-1500.**

Thank you and enjoy your purchase!

**AMERICAN CAR CRAFT
18924 SAKERA RD HUDSON FL 34667
Phone: 727 861-1500 Fax: 727 861-1520
www.americancarcraft.com**