



AMERICAN CAR CRAFT INSTRUCTION

Camaro Hood Emblem “RS” w/Carbon FiberPART#103019



PARTS INCLUDED:

- 1-Stainless Hood Emblem
- 1-Carbon Fiber Vinyl

1. Thoroughly clean the hood panel to remove any road grime and dirt.
2. You have been supplied with a background color. Peel the release liner from the back of this sticker and then carefully set it into the desired position. Press it onto the hood panel dry using your thumb. Using your thumb as opposed to a squeegee will actually allow you to set the sticker perfectly and offer you more control to do so without creating air bubbles. Also take a little time to make sure that you position is centered and nice and straight. Remove the transfer tape.

3. Now that you have your background color mounted straight and center the main emblem is just an easy peel and stick. Before you permanently stick the emblem you need to make a couple of dry runs to familiarize yourself with just how you will approach the position. The adhesive is very aggressive and will not allow you to reposition it once it makes contact so go slowly. When you are ready simply peel the red release liner from the back of the emblem being careful not to deform the emblem in the process. Bring the emblem close to the position and then firmly press it to the hood.

AMERICAN CAR CRAFT

18924 SAKERA ROAD-HUDSON FLORIDA 34667

Phone # 727-861-1500 Fax # 727-861-1520

www.americancarcraft.com