



AMERICAN CAR CRAFT INSTRUCTION

---

## CAMARO 4pc Wiper Cowl Instructions

### PART#103023



#### **PARTS INCLUDED:**

- 1-4pc Stainless Wiper Cowl
- 2-Adhesive Promoter Packs

#### **Liner info:**

Your new cover comes with a protective liner; do not remove liner until prompted by instructions.

This new stainless cover has been designed to add a little custom look to an area that up until now has been overlooked by all other custom stainless manufacturers.

1. The first and most important step in installing a part like this is preparation. Using a paper towel thoroughly scrub clean the entire surface area to be mounted first with alcohol to remove any and all road grime and dirt.

2. Apply a small length of masking tape to the cleaned area to see if you have achieved a tack. If so proceed to apply the adhesive promoter provided to the entire surface. This will insure a long lasting bond.

3. IMPORTANT! Before you permanently attach any of the four sections you will need to pre shape them by hand in order to achieve a nice contoured fit. This is extremely important in order to be confident that your installation will stay put and look good long term. The stainless is 22GA thick and you will be able to gently twist and roll the flat panels into a perfect contour. If you think about this for a moment , metal will not bend itself out of place so if you pre shape the sections perfectly PRIOR to installation you can expect the parts to stay just the way you have made them and they will not pop up out of place down the road.

4. Once you have achieved a nice contoured fit simply peel the red release liner from the back of each of the sections and then carefully set them into position. Press the sections firmly along the entire surface to set. Before you actually set the sections, place the two top sections onto the plastic wiper cowl. It is important that you understand that these two top sections have been designed to overlap the two smaller sections by about an eighth of an inch or more. So in order to achieve this, take a look at the two top sections to see how and where they place onto the factory cowl. Slide the two sections forward to create a ¼" overlap of the front area and take note of its position. Use a pencil to mark this position then remove the two sections.

5. Now that you have set up the tow top section you can go ahead and install the two smaller sections. It is important that you set these sections so that they are flush with the top edge and not overlapping this edge as this will cause the two top sections to not seat properly. Peel the red release liner from the back of the two sections and align them up to the split in the wiper cowl and then press firmly to set. Then set the larger top section and then finally the smaller top section. Press firmly along the entire surface to set the stainless. Remove the protective liner.

**If any questions occur during installation please contact American Car Craft @ 727-861-1500.**

**AMERICAN CAR CRAFT**  
**18924 SAKERA RD HUDSON FL 34667**  
**Phone: 727 861-1500      Fax: 727 861-1520**  
[www.americancarcraft.com](http://www.americancarcraft.com)