



## AMERICAN CAR CRAFT INSTRUCTIONS

### **Camaro 5pc "Super Sport" Cap Cover Set Automatic Part# 103075**



#### **PART INCLUDES:**

3-3/4" Chrome Caps (Brake Fluid Reservoir, Coolant Reservoir, & Washer Fluid Reservoir)

1-1" Chrome Cap (Oil Fill)

1-1/2" Chrome Cap (Power Steering Reservoir)

1-Pack Adhesive Promoter

1. The first step for installation will be to thoroughly scrub the tops of each of the factory caps, the oil/water/washer fluid/brake fluid/power steering. Scrub them with alcohol to remove any surface contaminants then swipe the tops with the adhesive promoter provided.
2. You have been provided with 2" furry Velcro attachment cookies for each cap. Peel the release liner from the back of each cookie and firmly set them to the top of each factory cap.
3. The factory wind shield washer fluid cap will need to be trimmed slightly in order for the new cover to sit nice and centered. To do this, simply snip the finger tab as well as the attachment strap off the cap with scissors
4. The set will contain a cap cover that is stuffed for the oil cap handle and a thinner cover for the power steering cap. The remaining covers in your kit are for all other factory caps. Simply set them in place.

**Thank you and enjoy your purchase!**

**If any questions occur during installation please contact**

**AMERICAN CAR CRAFT**

**18924 SAKERA ROAD-HUDSON FLORIDA 34667**

**Phone # 727-861-1500 Fax # 727-861-1520**

**[www.americancarcraft.com](http://www.americancarcraft.com)**