



**AMERICAN CAR CRAFT INSTRUCTION**

---

## **CHALLENGER 2pc BILLET STYLE HOOD SCOOP GRILLES PART # 152012**

### **PARTS INCLUDED:**

- \_\_\_2-Stainless Hood Scoop Grilles
- \_\_\_1-Adhesive Promoter Pen

- 1.** Thoroughly scrub the factory hood scoop grilles clean with household **Isopropyl Alcohol** (or rubbing alcohol) remove any and all waxes and dirt.
- 2.** Once properly cleaned take a piece of masking tape. Stick the test tape strip to the area in where you will be mounting your new trim. Test several areas, if it is tacky and sticks then proceed to the next step. If it is not sticking very well in any of the spots you tested then re-clean the area until the test strip sticks to all areas. If the test strips tape doesn't stick well neither will your new trim piece.
- 3.** Take your promoter pen included and wipe down the black plastic hood intakes where the new stainless steel grilles will mount. This clear promoter will not harm your plastic or paint. Let dry for three minutes.
- 4.** Take each of your new stainless steel grilles and hold them up to the air scoop intakes on your hood so you become familiar with how they fit.
- 5.** Now take one of the stainless steel grilles and remove the red liner around the perimeter exposing the sticky side of the tape underneath. Press the new grille inside the air scoop and hold firming for one minute.
- 6.** Repeat process for the other side.



BEFORE



*or*



AFTER

**If any questions occur during installation, please contact American Car Craft at 727 861-1500.**