

HEMI STAINLESS LETTERS 2PCS

PART#153009 patent pending



ITEMS NEEDED: Isopropyl alcohol ITEMS INCLUDED: Adhesive promoter 2-sets Stainless HEMI Letters

1. The first thing that must be done in order to install your new letters is to prep the surface area of the engine shroud factory letters. THIS IS A VERY IMPORTANT STEP! PLEASE FOLLOW CLOSLEY! Scrub these areas firmly first with soap and water let dry, then with household isopropyl alcohol, let dry and be sure to remove all flash residues from the surface. This composite plastic is stain resistant from the factory and is difficult to bond to, so be sure to scrub these areas very well. Once

completely scrubbed, swipe the factory letters once with the adhesive promoter (provided). REPEAT this same process for the opposite side.

2. Place the stainless steel letters into place and make note of their position. Be sure that you will be installing the letters in the center of the factory letters, before you remove the red liner. Once you are satisfied with where you will be placing your letters remove the red liner and reposition the letters and press firmly to set.

If you have used **any products** to make your engine cover "shine" you will need to make an extra effort in cleaning and preparing the surface for installation.

Returns are allowed only for parts with manufacturing defects. Installation errors are not manufacturing defects and parts can not be returned do to improper installation.

If any questions occur during installation, please contact American Car Craft at 727 861-1500.

Thank you and enjoy your new purchase.

Note: Care must be taken when cleaning your letters. It is a good idea to lightly dust your letters with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

> AMERICAN CAR CRAFT 18924 SAKERA ROAD-HUDSON FLORIDA 34667 Phone # 727-861-1500 Fax # 727-861-1520 www.americancarcraft.com