



AMERICAN CAR CRAFT INSTRUCTION

**G8 Polished Radiator Cover w/3 Caps GT 08-09
PART# 223004**



PARTS INCLUDED:

- 4-6mm Allen Head Bolts
- 4-Large Chrome Cap Covers
- 3-Chrome Cap Covers 2@3/4" & 1@1/2"
- 1-Adhesive Promoter Pack

- 1. Thoroughly clean the top of each factory cap with alcohol to remove dirt. Then swipe the tops with the adhesive promoter provided.**
- 2. You will notice that each of the caps contain a Velcro cookie attached to the underside. Peel the cookie half and then remove the release liner from the back of the cookie, press it firmly onto the top of the factory cap. Once this is done simply place the decorative cap in place.**
- 3. The G8 windshield washer fluid reservoir cap will need to be trimmed in order to accept the new decorative cap. Simply trim the soft plastic strap and excess shape using a scissor so that the new decorative cover will be able to be placed over it.**

**AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com**