

AMERICAN CAR CRAFT INSTRUCTIONS

2005-2009 V6 & GT MUSTANG 2-pc AIR BOX COVERS PART#273001 patent pending



PARTS INCLUDED:

2-STAINLESS COVERS 1-ADHESIVE PROMOTER 1-TEST KIT

Your new covers come to you with a protective liner. Do not remove liner until installation is complete.

1. Prep the top of the factory air box by rubbing with household isopropyl alcohol to remove all dirt and grime then swipe once with the adhesive promoter provided. PLEASE NOTE: If this area has been treated with silicones such as Armor-all or any other such treatments installation will not be possible. Please refer to the SPECIAL INSTRUCTIONS attached.

- 2. Start with the flat cover. Your new cover come to you pre shaped however it will be necessary to adjust this shape by hand until you have achieved a nice contoured fit without forcing. This may require you to shape and reshape several times until you get it just right.
- 3. Once you have achieved a nice contoured fit remove the red liner and set into place pressing firmly to achieve a nice permanent bond.
- 4. Next install the air tube. Remove the wire connector from the flow sensor. It will seem like your new air tube is rolled too tight to install however the tube will open enough for the installation by spreading the seam and forcing the tube over the flow sensor then allow the cover to snap over the entire tube. Once in position squeeze the tube with both hands to restore its shape. Reconnect the wire connector to the flow sensor. Remove the protective liner.

Note: Care must be taken when cleaning your covers. It is a good idea to lightly dust your covers with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

If any questions occur during installation please contact American Car Craft @ 727-861-1500

Thank you and enjoy your purchase!

AMERICAN CAR CRAFT 18924 SAKERA ROAD-HUDSON FLORIDA 34667 Phone # 727-861-1500 Fax # 727-861-1520

www.americancarcraft.com