



AMERICAN CAR CRAFT INSTRUCTION

2011-2014 Mustang GT 5.0 2pc Stock Air Box Cover Part #273052



Perforated Shown

Parts Included:

- 1-Stainless Air Tube Cover
- 1-Stainless Filter Box Cover
- 1-Adhesive Promoter Pack

Introduction: This all new cover has been designed to peel and stick directly to the factory air tube and filter box. The kit will allow you to utilize the externally efficient cold air box and dress it up to a truly custom looking set up. By installing a high efficient filter such as a K&N or any other factory high efficiency replacement filters you can enjoy a custom looking high performance air filter system at a fraction of the cost.

Liner info: Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and or possible scratches during installation. This liner is required to remain on the part until you are instructed to remove it.

1. The first thing to do will be to thoroughly scrub clean the top surface of the factory air tube and filter box to remove any and all road grime and dirt. Then swipe that entire area with the adhesive promoter provided. This chemical is NOT a cleaner but an adhesive accelerator and must be used as such in order to achieve a nice strong long term bond.

2. The next step will be to snap on the cylinder collar to the factory air tube. Simply peel the red release liner from the inside of the tube and then snap it over. Press along its length to set the attachment tape. It is important to understand the cover will not completely contour to the factory tube. That is to say some areas will not attach at all however the tube will contour pretty nicely leaving you with a nice looking cover firmly set in place. Remove the protective liner.
3. The next section will also peel and stick in place only with this section you will need to tweak the shape of the section so that it contours to the factory air box perfectly. The cover comes to you pre-shaped however you **MUST** contour the part further by hand in order to achieve a nice complete bond. Once you have achieved a nice shape simply peel the red release liner from the back of the part and then carefully set it atop the box area pressing firmly along its perimeter to set the bond. Peel the protective liner to finish the installation.

If any questions occur during installation please call American Car Craft at 727-861-1500.

Thank you for your purchase!

**AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com**