



AMERICAN CAR CRAFT INSTRUCTION
Chrysler SRT 8 HEMI Fuel Rail Covers Polished/Perf
w/Factory Intake
Part# 303013



PARTS INCLUDED:

- 2-Stainless Valve Covers
- 2-Adhesive Promoter Packs
- 6-2pc Velcro Attachment Cookies
- 1-Decorative Chrome Cap Cover/w Velcro Cookie

These new covers are made of the best quality 304 stainless polished to a beautiful mirror finish. They have been carefully designed to fit over the factory plastic covers and mount together via Velcro attachment tape.

Your new covers come to you with a protective liner. Do not remove liner until instructed to do so.

1. Thoroughly clean the face of the factory covers with alcohol to remove any and all road grime and dirt. Then swipe the front 3 extruded areas above the coil packs with the adhesive promoter provided and lastly to the very front side of the plastic cover. This promoter is NOT a cleaner but an adhesive accelerator and will ensure a nice permanent bond long term and MUST be used.
2. You have been provided with six Velcro attachment cookies. Peel the release liner from both sides of each cookie and place them on the 3 areas above the coil packs that you just promoted. The front side does NOT receive a Velcro cookie.

3. Swipe the underside of the new covers with the adhesive promoter and then carefully place them over the factory covers. Press them down firmly to set the Velcro cookies. Although it should not be necessary the new cover shape may need to be tweaked a little in order to achieve a nice perfect contour. Should this be necessary simply take a look at the overall shape and fitment to determine what adjustments are apparent then simply remove the new cover and gently form by hand. Also at this time you might want to firmly press the Velcro cookies on the underside of the covers to ensure a nice bond, then simply reinstall.
4. You have been provided with two stainless end caps. With the new covers firmly in place peel the red release liner from the back of the two inserts and then firmly press them into position making sure that they sit into the shape of the new cover without exposing any gaps. The smaller one is for the driver side and the larger for the passenger side. At this time you may remove all the protective liner from the covers. NOTE: In some production models there may be a large wire harness routed in front of the factory fuel rail cover, should this be the case simply reroute the harness to the side to create adequate clearance for the new front plate. This may require you to detach the harness hold down from the valve cover bolts in order to allow you to force the harness cover to the side.
5. The last part of this install will be to set the decorative chrome cap atop the factory oil fill cap by cleaning the cap with alcohol to remove dirt then swipe the cap with the remaining adhesive promoter. Remove the Velcro cookie halves from the underside of the cap and firmly press it to the factory cap then simply set the new cap cover in place.

**If any questions occur during installation please contact American Car Craft at
727-861-1500**

Thank you and enjoy your purchase!

**AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com**