



**AMERICAN CAR CRAFT INSTRUCTIONS**

## **300 LOWER HOOD COWL**

**PART#303021**



**Parts Included:**

- 1-Lower Hood Cowl
- 1-Packet of adhesive promoter

**Your cover comes to you with a protective liner. Do not remove liner until final installation.**

1. Wash area to be installed first with soap and water to remove dirt. Then apply household isopropyl alcohol to prepare the surface for adhesion.

2. NOTE: It will be necessary to have a friend help you with this installation. Standing on both the driver and passenger side of the lower hood area hold your new insert and place into area to determine its exact position. Please note your new cowl plate ships to you flat so it will be necessary to gently mold the plate by hand to achieve a nice contoured fit to your hood. Make sure that it sits uniformly from side to side and mark the insert and hood at the very center and at the far left and right to mark level.

3. Please note installation of this panel is permanent and once positioned will not allow re positioning. It is advisable to make a couple trial runs for positioning before removing the red liner. Once the liner is removed you will only have one shot at attaching this insert so take your time. Once you feel confident that you can place the panel in position properly, Peel the red liner and reposition. Press firmly to set. Remove the protective liner.

**If any questions occur during installation please call American Car Craft at 727-861-1500.**

**Thank you and enjoy your purchase!**

**CARE AND MAINTENANCE:**

**Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.**