



AMERICAN CAR CRAFT INSTRUCTIONS

Charger Door Lock Trim 4Pc Kit

PART #331006



Parts Included:

- 4-Stainless Trim Rings
- 1Adhesive Promoter Tube

Introduction: Dress up the interior of your **NEW** 2011-2012 Dodge Charger with our Polished Stainless 4pc Door Lock Trim! These trim rings are made from the finest T304 polished stainless and have been designed to attach using 3M attachment tape. Easy Installation, compliments our complete interior stainless trim accessories. Will never tarnish, rust or pit!

!!!!!!VERY IMPORTANT!!!!!!

BEFORE YOU BEGIN YOU MUST FIRST PREP YOUR DASH/DOOR AREAS WHERE PIECES ARE GOING TO BE INSTALLED IN ORDER TO ALLOW ADHESION!!!!. You can do this by scrubbing the entire area first with household isopropyl alcohol. **NOTE: If these areas have been treated with armor all or any such surface protector; installation will NOT work unless these treatments have first been removed using special chemicals. PLEASE REFER TO THE SPECIAL PREPARATION INSTRUCTION SHEET ENCLOSED.**

We cannot be responsible for kits not sticking do to improper preparation!

PLEASE NOTE: Installation errors are NOT manufacturing defects and parts can NOT be RETURNED due to improper installation.

1. Once your areas have been prepared use the adhesive promoter packs/tubes (provided) to wipe the areas of your dash/door that will be covered with your new stainless pieces. Allow a few seconds to dry.

You have been provided with attachment tape test strips. Use one of these to test the tack. If it seems to stick well then you can proceed with your installation. If you cannot get the test tape to stick please refer back to the special preparation instruction sheet and repeat those procedures.

2. **IMPORTANT!!** Before you remove the liner for permanent attachment place each piece into position and check the fit and also get acquainted with just how each part sets in place. It **WILL** be necessary to form a few of the parts by hand to **CONFORM** to the shape of your dash to insure a nice perfect fit without forcing the shape. Once you are satisfied with the shape and fit peel the red release liner and firmly press each piece into position.

If any questions occur during installation please contact American Car Craft @ 727-861-1500.