



AMERICAN CAR CRAFT INSTRUCTIONS

2015-2016 Dodge Charger/ Challenger Polished Fuse Box Cover Part #333026Patent Pending



PARTS INCLUDED:

1-Stainless Fuse Box Cover 4-Velcro Attachment Cookies 1-Pack of Adhesive Promoter

Your new cover comes to you with a protective liner. Do not remove liner until installation is complete.

- 1. Clean the entire top of the factory fuse box first with soap and water to remove any dirt and grime then scrub it with household rubbing alcohol until it is completely clean. Swipe the entire area you just cleaned with the adhesive promoter provided.
- 2. You have been provided with 4 Velcro attachment cookies. Swipe the underside of your new stainless fuse box cover with the adhesive promoter provided. Peel the release liner off one side of these cookies and place them on each corner of the underside of the fuse box cover and press firmly on them to set. Then pull the release liner off the top half of all the cookies. Place your new cover into position and press firmly over the entire cover to make sure all the cookies make contact.

TECH NOTE: Depending on the year of the vehicle it may be necessary to remove the red post cover as well as lowering the extra height of the metal post itself. This can be done by simply snipping off any excess with a pair of bolt cutters. This will prevent any possibility of the bolt meeting the new cover. It also may be necessary to reposition the windshield washer tube and tuck the line under the fender ridge rerouting the line to allow a nice placement of the new cover.

3. Remove protective liner.

Thank you and enjoy your purchase!

If any questions occur during installation, please contact

AMERICAN CAR CRAFT

18924 SAKERA ROAD-HUDSON FLORIDA 34667

Phone # 727-861-1500 Fax # 727-861-1520

www.americancarcraft.com