



Firewall Polished Stainless Hellcat

2015-2016



AMERICAN CAR CRAFT INSTRUCTIONS

2015-2016 Charger HELLCAT Polished Firewall

Part# 333057



PARTS INCLUDED:

2-3/4" Oval Head Screws

PLEASE READ ENTIRE INSTRUCTIONS BEFORE BEGINNING INSTALLATION!

Your new firewall comes to you with a protective liner. **Do not remove liner until instructed.**

1. Your new firewall panel comes to you flat. In order to achieve a nice conforming fit along the wiper cowl gasket ridge, it will be necessary to slightly form the panel by hand. To do this you will need to remove it, shape it some, and place it back into position several times until the panel begins to sit relatively parallel to the wiper cowl ridge. We have experienced the transmission dip stick can be over to one side or the other from car to car should this be the case with your vehicle the tube can easily be adjusted by inserting a large long screwdriver into the tube. This will give you ideal leverage to nudge the tube so that you can achieve a nice centered appearance. Once you are satisfied with the fit drill two 9/64 holes directly thru the upper chrome trim and into the cowl ridge. Just to the left and right side of the firewall, you will notice two large plastic circular cowl retainers on the cowl. These are good locations to place screws thru the firewall to hold it securely.
2. Once the holes are drilled, remove the protective liner. Then secure with the two chrome oval head screws (provided), just enough so that the head of the screw countersinks itself into the chrome trim. Be sure not to over tighten.

Thank you and enjoy your purchase!

If any questions occur during installation please contact
AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com