



AMERICAN CAR CRAFT INSTRUCTIONS

HHR STAINLESS REAR BUMPER CAP

PART #422004



PARTS INCLUDED:

- ___ 1-Stainless Brushed Bumper Cap
- ___ 1-Adhesive Promoter Packet
- ___ 1-Adhesive Promoter Tube
- ___ 1-Length of 1/8" Chrome Trim - 47"

This accessory comes to you with a clear protective liner. Do not remove this liner until installation is complete.

Your new bumper cap has been designed to set into the formed area on your factory bumper offering a nice custom look as well as protection for the bumper area.

1. Thoroughly clean the factory bumper inset area with rubbing alcohol to remove any dirt and wax that may be present. Then swipe the area once with the adhesive promoter packet provided.
2. Before you permanently install your new insert place it in position to get acquainted with its position as well as the procedure of placement. It is important to be able to set the insert in such a way as to line up the part with the factory groove of the bumper. So it is important to practice the positioning a little. The attachment tape is very aggressive and will only allow one shot at final placement. Once you have familiarized yourself with the placement peel the red release liner from the back of the insert and carefully place into position. Then press firmly to set.
3. Apply a bead of adhesive promoter tube along the edge of the insert directly to the paint. You have been supplied with a length of chrome trim. This trim is to be used to finish the edge of the insert. Peel a small length of the red release liner from one end of the trim and set in position so that the trim inserts into the groove on its side capping the edge of your stainless insert and work your way around to the opposite side then snip off any excess trim with a scissor and press firmly along the entire length to set. Peel the protective liner.

**If any questions occur during installation please contact American Car Craft @
727-861-1500**

Thank you and enjoy your purchase!

Note: EXTRA CARE must be taken when cleaning your stainless trim. It is a good idea to lightly dust your trim with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com