



AMERICAN CAR CRAFT INSTRUCTIONS

**HHR Chrome ABS Eyebrow Kit
PART#422008 patent pending**



PARTS INCLUDED:

- 2-Chrome Eyebrows
- 2-Chrome Molding Strips 43"
- 1-Adhesive Promoter Pack
- 1-Adhesive Promoter Tube
- 1-Plastic Squeegee

Your new headlight kit comes to you with a clear protective liner. Do not remove the liner until the end of step 2.

- 1. Clean your headlight first with soap and water and then with household isopropyl alcohol and let dry. Then swipe the area ONLY where you will be placing your new cover with the adhesive promoter packet (provided). BE CAREFUL NOT to apply the adhesive promoter to the clear area of the lens where the chrome will not be covering because it will leave a visible smear. If a smear occurs simply remove it with household rubbing alcohol after the installation is complete. Once you have carefully applied the adhesive promoter correctly you may begin the installation.**

- 2. Please refer to pictures as you continue thru steps 2 and 3. Place the new cover over the headlight so that it fits along the upper edge of the headlight and make note of its position. If positioned correctly you will have about a 1/4" space between the edge of the eyebrow and the edge of the light. NOTE: This space will be covered by the chrome trim in the following steps. Once you have a good position draw the position directly to the headlight with a fine marker. Also add 2 vertical lines crossing over the new cover onto the headlight. These marks will give you accurate placement. Now you may begin permanent installation by peeling the release liner from the underside and carefully reposition the new cover at the placement marks you just applied and work the new cover onto the headlight using the hard plastic squeegee provided press down on the cover nice and evenly to attach it without any air pockets. Remove the protective liner.**

- 3. You have been provided with a length of chrome trim. This trim is designed to cap the headlight cover you just installed and to border the entire headlight. Apply a small bead of the adhesive promoter from the tube (provided) around the edge of the headlight. Then begin placing the trim starting at the bottom center edge of the headlight. Work your way around to the start point pulling the red release liner as you go. As you approach each corner pre-bend the trim between your fingers and your thumb so that the trim takes the shape of each corner without forcing. Once you come to the start point mark the overlap slightly longer then trim the molding on the mark with a pair of scissors. Buckle the two ends together and press firmly to set a nice tight seam. Press the entire trim to permanently set. Repeat steps 1-3 for opposite side. TECH TIP: Use a little instant adhesive at the butt seam to eliminate separation or shrinkage of the molding over time.**

DO NOT GET WET FOR 24 HOURS.

IF ANY QUESTIONS OCCUR DURING INSTALLATION PLEASE CONTACT AMERICAN CAR CRAFT AT 727-861-1500.

Thank You and Enjoy Your New Purchase!







HHR
PASS
SIDE



AMERICAN CAR CRAFT
18924 SAKERA RD HUDSON FL 34667
Phone: 727 861-1500 Fax: 727 861-1520
www.americancarcraft.com