



Muffler Plate Polished

2001-2005



AMERICAN CAR CRAFT INSTRUCTIONS

PT Cruiser Stainless Stock Muffler Plate Part# 713011



PARTS INCLUDED:

1-Muffler Plate

PARTS REQUIRED:

Household Silicone

1. Remove the bolt securing the factory ground strap to the muffler. **NOTE:** If you have installed an aftermarket exhaust tip you will need to remove it to install this plate. Once plate has been installed you may replace your tip.
2. Clean the face of your muffler of any and all road grime and dirt. Then scrub the surface with household rubbing alcohol and let dry.
3. Place a large blob of clear household silicone directly to the face of the muffler (Doing this will ensure that your new plate does not vibrate or rattle) then slip your new muffler plate into position by sliding the cover over the exhaust tip then rotate it around until it lines up with the bolt hole you exposed earlier. Position the cover so that it is centered and press into the silicone. Then reattach the ground strap and bolt that you removed in step one. Replace your aftermarket tip if equipped.

**If any questions occur during installation, please contact American Car Craft at
727-861-1500**

Thank you and enjoy your purchase!

AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com