



# AMERICAN CAR CRAFT INSTRUCTIONS

---

## *Raptor Carbon Fiber Taillight Wraps*

**PART #772004**



### **Parts Included:**

- 2-Carbon Fiber Wraps
- 1-Adhesive Promoter Pack
- 1-Felt Squeegee

**Introduction:** This unique graphic will enhance the body styling of your Raptor with a quality carbon fiber look that is easy to install and offer a nice custom look

**Liner Information:** Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and or possible scratches during installation.

1. Thoroughly scrub clean the areas of the Raptor body with alcohol to remove any and all wax and dirt.
2. Test that you have done a good job at this by applying ordinary masking tape to a few areas to see if that tape sticks well. If there is any waxes left the tape will not adhere. If this happens, simply re- clean the area until you achieve a tack.
3. You have been supplied with and adhesive promoter applicator. This promoter is to be applied to the very rim of the body line **ONLY!** This will insure that your new graphic will permanently bond to the paint long term. Do **NOT** apply this chemical to the entire body of the graphic area.
4. Now that you have successful prepared your Raptor to receive the graphic place each section into their appropriate spot to get yourself acquainted with just how they are intended to fit. Draw a cross hair along the

edge of the graphic with a pencil for exact placement. This is important because we will recommend that the graphic be put on dry for the best results. Although the graphic can be put on wet this would add a significant amount of time and effort to the installation and will make the installation a lot more difficult than it needs to be.

5. Once you have a good idea of how they will fit simply peel the release liner from the back of the graphic and then carefully set the graphic in place and then swipe the graphic with the felt squeegee provided. Be careful not to stretch the graphic as you squeegee it as this will cause an undesirable overlap of the body ridge. Set all the other sections in the same way to finish the installation.

**If any questions or problems occur during installation, please contact American Car Craft at 727-861-1500.**

**Thank You and Enjoy Your Purchase!**

**AMERICAN CAR CRAFT**  
**18924 SAKERA RD HUDSON FL 34667**  
**Phone: 727 861-1500      Fax: 727 861-1520**  
**[www.americancarcraft.com](http://www.americancarcraft.com)**