



**AMERICAN CAR CRAFT INSTRUCTION**

**2003-2006 Dodge Viper Air Box Letters  
PART#973002**



**PARTS INCLUDED:**

**1-V-10 505 Letter Set**

**1-Promoter Packet**

- 1. You should have pieces that spell out "V-10" & "505"**
- 2. Wash the area on your engine air box where you are going to mount the numbers.**
- 3. Set each number on top of box to see how it fits.**
- 4. Once you are comfortable with how each number fits take your promoter packet or pen and open it (you must snap the pen at its midpoint to initiate it). Wipe down the raised 3-D numbers on the Air-box where you are doing to mount your new stainless steel numbers.**
- 5. Let dry for 2 minutes. Remove the back off one number at a time and place it on top of the air box where it goes. Press firmly all along the surface of the each number.**

6. If your numbers have a clear plastic protective seal on top of them you may peel it off at this time.
7. Let sit overnight.
8. Clean with a good glass cleaner as needed.

**Note: Care must be taken when cleaning your sills. It is a good idea to lightly dust your sills with a clean soft cloth first in order to prevent any particles from scratching them. Then wipe (using a new clean soft cloth or bounty paper towel) with a good quality streak free glass cleaner.**

**If you have any questions during installation please call American Car Craft at 727-861-1500.**

**Thank you and enjoy your new purchase!**

**AMERICAN CAR CRAFT**  
**18924 SAKERA ROAD-HUDSON FLORIDA 34667**  
**Phone # 727-861-1500 Fax # 727-861-1520**  
**[www.americancarcraft.com](http://www.americancarcraft.com)**